

THE BIG LEBOWSKI™

PINBALL RULES FLOWCHART



Hold left flipper on ball launch

Hold right flipper on ball launch

Rug

Collect flashing top lane

Mini ramp

RUG SKILL SHOT

SKILL SHOT

BOWLING SKILL SHOT

Opens the rug

Lights LET'S GO BOWLING

Left target

Re-spell M-A-U-D-E in top lanes

Make X spins on spinner

Hit Nihilist targets X times

Mini ramp to spell B-O-W-L-I-N-G

Complete right target bank

TRAMPOLINE

BONUS X INCREASE

MYSTERY

NIHILIST SHOWDOWN

LET'S GO BOWLING

WHITE RUSSIAN

Scoop

Hit both LIGHT / LOCK Targets

Repeat to increase mystery level

Scoop

Upper scoop or saucer

Any blinking WR shot

EXTRA BALL

MULTIBALL

Level 3 mystery award

NIHILIST SHOWDOWN

Complete challenge to collect ball & a perk

Following X shots are multiplied

repeat twice

Left ramp

Bash rug to open

Hit X parking targets

Spell any character (the more the merrier)

Spell Z-E-R-O

Collect all Jackpots

Rug hole

Upper scoop

Saucer

Collect X times

Left ramp

RUG MODE

CAR MODE

- Easier Car Modes
- Easier Rug Modes
- Super Jackpot pre-lit
- Easier BOWLING spelling
- Untimed Mark It Zero

Each ball multiplies its character's jackpot

CHARACTER MULTIBALL

Saucer

SUPER JACKPOT

Start all Rug Modes

Start all Car Modes

Collect all bowling balls

Start all characters

MARK IT ZERO

RUG MODES

CAR MODES

COLLECT BALLS

START CHARACTERS

Scoop

THE DUDE ABIDES